



30" Deep Main Desk Pedestal BF
24" Deep Cedenza-Return Pedestal
P.1


| | | | | |
|---|---|---|--|---|
| 1 | 2 | 3 | A | B |
|  |  |  |  |  |
| Keys 2 Pcs | Screw M6*15 15 Pcs | M4 Allen Wrench 1 Pc | Pedestal 1 Pc | Metal Leg 1 Pc |


IMPORTANT NOTE:

Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched
 Check that you have all parts and hardware.
 Remove all wrapping materials, including staples & packing straps before you start assemble.
 Do not tighten all screws or bolts until all completely assembled.
 Keep all hardware parts out of reach of children.

24" Deep Cedenza-Return Pedestal

P.2

- 1 Use the screws (2) to attach the metal leg (B) under the Pedestal (A)

Notes: This Assembly Instruction applies to all Pedestals of Main Desk, Credenza and Return.

