




| | | |
|---|--|---|
| (1)x1 | (2)x1 | (3)x1 (L)x1 (R) |
|  |  |  |
| Back | Seat | Right & Left Arm |
| (4)x1 | (5)x1 | (6)x1 |
|  |  |  |
| Mechanism | Gas Lift | Base |
| (7)x5 | <p>(A)*4  M8*22 Mechanism Screw</p> <p>(B)*8  M6*22 Arm Screw</p> <p>(C)*8  Arm Cap</p> | |
|  | Casters | |



Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.

